

Product Installation Instructions for Lifting Kits

Important: Please read these instructions fully before commencing installation. Failure to follow instructions fully will invalidate warranty.

We recommend that installation be carried out by appropriately qualified personnel. Protective gloves, safety glasses and clothing must be used during installation.

What you'll need:

Screwdriver: posidrive no2 (or electric), Pencil/Marker

We supply (please check):

Adjustable Legs and screws, Spring clips with screws, Appropriate fascia/fascias



Fitting Spring Clips to base of unit



Carefully place the unit on its side on the floor or on a table.

Attach a spring clip, using the screws provided, so that it touches the very edge of the "skirt"

Attach all the spring clips provided, spread evenly.

Attaching the adjustable legs



Using the screws provided, screw the feet to the bottom of the unit.

Attach all the feet provided

Spread the feet evenly.



Stop for lunch, nice roll with a cuppa!



Push the adjustable legs firmly into the feet.

Attaching the fascia





Bring the fascia to the unit and, attach between the spring loaded clips and the unit.

Line up the middle of the arc on the fascia with the middle of the arc on the unit, do this by sliding the fascia left to right until it sits nicely.

You will have excess on one or both sides.

Remove the excess. (you might want to remove a bit extra to allow for skirting boards).

Unclip the fascia and, carefully, manoeuvre the unit into the upright position. Be careful not to break the legs. Adjust the legs to ensure the unit is level.

Ensure the unit is in its final position before re-attaching the fascia.

When legs are attached, extra care must be taken when moving the unit, Lift don't Drag.

Always use the screws provided. If the wrong screws are used, it could result in damage to the tray!

Thank you for purchasing this Neptune Bathing Product.

We wish you many years of trouble free usage.

If you need any help or advice, please call Neptune Bathing Ltd.

Phone 00 353 (0) 1 8250840



Your statutory rights are not affected by these instructions.